

**CERTIFICATE OF
 CALIBRATION**



Certificate No. ACT-1272

CERTIFICATION NUMBER CP134-00089-840 FOR Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902 TEST INSTRUMENT Height Gages Digital MAKE Tesa MODEL Tesa-Hite 700 RANGE (0 to 28") CUSTOMER LOCATION Location1 Location2 CONDITION RECEIVED In Tolerance CONDITION RETURNED In Tolerance CALIBRATED BY Josh Weimer REVIEWED/ISSUED D.P. 07/29/2025 CALIBRATION LOCATION FVM ENVIRONMENT 69.0°F, 31.0%RH, 28.92inHg CALIBRATION DATE 05/14/2025 RECALIBRATION DUE 05/14/2026	IDENTIFICATION HT-005A SERIAL NUMBER 89 PURCHASE ORDER # PROCEDURES FOLLOWED HT-005A rev. 1 STANDARDS USED <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>FVS-682</td> <td>36PCS-150079</td> <td>C0145-27773-590</td> <td>05/31/2025</td> </tr> <tr> <td>FVS-788</td> <td></td> <td>CP017-24373-690</td> <td>01/31/2026</td> </tr> <tr> <td>FVS-873</td> <td></td> <td>CP097-41651-590</td> <td>04/30/2026</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVS-682	36PCS-150079	C0145-27773-590	05/31/2025	FVS-788		CP017-24373-690	01/31/2026	FVS-873		CP097-41651-590	04/30/2026
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL														
FVS-682	36PCS-150079	C0145-27773-590	05/31/2025														
FVS-788		CP017-24373-690	01/31/2026														
FVS-873		CP097-41651-590	04/30/2026														



CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Range	(in)	(in)	(in)	(in)	(in)	(in)
	0.37000	0.36982	0.37018	0.37003	0.37003	9.8E-6
	1.00000	0.99982	1.00018	0.99989	0.99989	1.2E-5
	1.60000	1.59982	1.60018	1.59996	1.59996	1.4E-5
	3.00000	2.99982	3.00018	2.99982	2.99982	1.9E-5
	5.00000	4.99982	5.00018	4.99989	4.99989	2.6E-5
	12.00000	11.99982	12.00018	12.00016	12.00016	4.9E-5
	18.00000	17.99982	18.00018	18.00013	18.00013	7.0E-5
	28.00000	27.99980	28.00020	28.00003	28.00003	1.0E-4
Repeat	(in)	(in)	(in)	(in)	(in)	(in)
	0.00000	-0.00005	0.00000	0.00000	0.00000	8.5E-6

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration. Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.