

**CERTIFICATE OF
 CALIBRATION**



Certificate No. ACT-1272

CERTIFICATION NUMBER CP134-00225-840 FOR Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902 TEST INSTRUMENT Height Standard Height Riser MAKE Starrett MODEL 258R RANGE 12" CUSTOMER LOCATION Location1 Location2 CONDITION RECEIVED In Tolerance CONDITION RETURNED In Tolerance CALIBRATED BY John Gardner REVIEWED/ISSUED D.P. 07/29/2025 CALIBRATION LOCATION FVM ENVIRONMENT 69.0°F, 31.0%RH, 28.92inHg CALIBRATION DATE 05/14/2025 RECALIBRATION DUE 05/14/2026	IDENTIFICATION HT-006B SERIAL NUMBER 225 PURCHASE ORDER # PROCEDURES FOLLOWED HT-006B rev. 1 STANDARDS USED <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>T-0345</td> <td>210003</td> <td>C0088-47186-418</td> <td>07/31/2025</td> </tr> <tr> <td>T-0446</td> <td></td> <td>CN278-39469-364</td> <td>07/31/2025</td> </tr> <tr> <td>T-0523</td> <td>ADT05390199</td> <td>C0010-33362-689</td> <td>07/31/2025</td> </tr> <tr> <td>T-0967</td> <td>C8922</td> <td>CN306-35954-589</td> <td>07/31/2025</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	T-0345	210003	C0088-47186-418	07/31/2025	T-0446		CN278-39469-364	07/31/2025	T-0523	ADT05390199	C0010-33362-689	07/31/2025	T-0967	C8922	CN306-35954-589	07/31/2025
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL																		
T-0345	210003	C0088-47186-418	07/31/2025																		
T-0446		CN278-39469-364	07/31/2025																		
T-0523	ADT05390199	C0010-33362-689	07/31/2025																		
T-0967	C8922	CN306-35954-589	07/31/2025																		



CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Height	(in)	(in)	(in)	(in)	(in)	(in)
Foot 1	10.00000	9.99996	10.00004	10.00000	10.00000	1.4E-4
Foot 2	10.00000	9.99996	10.00004	10.00000	10.00000	1.4E-4
Foot 3	10.00000	9.99996	10.00004	10.00004	10.00004	1.4E-4
Average	10.00000	9.99996	10.00004	10.00001	10.00001	1.4E-4

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration.
 Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.