

**CERTIFICATE OF
 CALIBRATION**



Certificate No. ACT-1272

<p>CERTIFICATION NUMBER CP134-00253-840</p> <p>FOR Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902</p> <p>TEST INSTRUMENT Indicators Dial</p> <p>MAKE Fowler</p> <p>MODEL 0-.250"/0.0005"</p> <p>RANGE (0 to 0.250) in</p> <p>CUSTOMER LOCATION Location1 Location2</p> <p>CONDITION RECEIVED In Tolerance</p> <p>CONDITION RETURNED In Tolerance</p> <p>CALIBRATED BY Chris Noel</p> <p>REVIEWED/ISSUED D.P. 07/29/2025</p> <p>CALIBRATION LOCATION FVM</p> <p>ENVIRONMENT 69.0°F, 31.0%RH, 28.92inHg</p> <p>CALIBRATION DATE 05/14/2025</p> <p>RECALIBRATION DUE 05/14/2026</p>	<p>IDENTIFICATION HT-020I</p> <p>SERIAL NUMBER 253</p> <p>PURCHASE ORDER #</p> <p>PROCEDURES FOLLOWED HT-020I rev. 1</p> <p>STANDARDS USED</p> <table border="1"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>FVM-131</td> <td>TG2103-1070</td> <td>CP041-20520-924</td> <td>07/31/2025</td> </tr> <tr> <td>FVR-119B</td> <td>16782367.21</td> <td>C0213-33882-690</td> <td>07/31/2025</td> </tr> <tr> <td>FVR-181</td> <td>63144991</td> <td>C0275-25482-350</td> <td>07/31/2025</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVM-131	TG2103-1070	CP041-20520-924	07/31/2025	FVR-119B	16782367.21	C0213-33882-690	07/31/2025	FVR-181	63144991	C0275-25482-350	07/31/2025
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL														
FVM-131	TG2103-1070	CP041-20520-924	07/31/2025														
FVR-119B	16782367.21	C0213-33882-690	07/31/2025														
FVR-181	63144991	C0275-25482-350	07/31/2025														



CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Range	(in)	(in)	(in)	(in)	(in)	(in)
	0.0010	0.0005	0.0015	0.0010	0.0010	6.0E-5
	0.0050	0.0045	0.0055	0.0050	0.0050	6.0E-5
	0.0100	0.0095	0.0105	0.0100	0.0100	6.0E-5
	0.0200	0.0195	0.0205	0.0200	0.0200	6.0E-5
	0.0250	0.0245	0.0255	0.0250	0.0250	6.0E-5
	0.0500	0.0495	0.0505	0.0500	0.0500	6.0E-5
	0.1000	0.0995	0.1005	0.1000	0.1000	6.0E-5
	0.2000	0.1995	0.2005	0.2000	0.2000	6.0E-5
	0.2500	0.2490	0.2510	0.2500	0.2500	6.0E-5
Repeat	(in)	(in)	(in)	(in)	(in)	(in)
	0.0000	-0.0005	0.0005	0.0000	0.0000	6.0E-5

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration. Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.