

**CERTIFICATE OF  
 CALIBRATION**



Certificate No. ACT-1272

<b>CERTIFICATION NUMBER</b> CP134-00395-840 <b>FOR</b> Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902 <b>TEST INSTRUMENT</b> Tape Measure <b>MAKE</b> Lufkin <b>MODEL</b> 1012 (12 ft) <b>RANGE</b> (0 to 12) ft <b>CUSTOMER LOCATION</b> Location1 Location2 <b>CONDITION RECEIVED</b> In Tolerance <b>CONDITION RETURNED</b> In Tolerance <b>CALIBRATED BY</b> Mike Stini <b>REVIEWED/ISSUED</b> D.P. 07/29/2025 <b>CALIBRATION LOCATION</b> FVM <b>ENVIRONMENT</b> 69.0°F, 31.0%RH, 28.92inHg <b>CALIBRATION DATE</b> 05/14/2025 <b>RECALIBRATION DUE</b> 05/14/2026	<b>IDENTIFICATION</b> DM-005C <b>SERIAL NUMBER</b> 395 <b>PURCHASE ORDER #</b> <b>PROCEDURES FOLLOWED</b> DM-005C rev. 1 <b>STANDARDS USED</b> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>FVC-033</td> <td>5075AA1A090465</td> <td>CP112-56053-337</td> <td>07/31/2025</td> </tr> <tr> <td>FVC-064</td> <td>303-5305C</td> <td>C0032-46505-411</td> <td>07/31/2025</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVC-033	5075AA1A090465	CP112-56053-337	07/31/2025	FVC-064	303-5305C	C0032-46505-411	07/31/2025
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL										
FVC-033	5075AA1A090465	CP112-56053-337	07/31/2025										
FVC-064	303-5305C	C0032-46505-411	07/31/2025										



**CALIBRATION RESULTS**

\* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Length	(in)	(in)	(in)	(in)	(in)	(in)
	12.000	11.969	12.031	12.000	12.000	6.0E-4
	24.000	23.969	24.031	24.000	24.000	6.0E-4
	48.000	47.969	48.031	48.000	48.000	6.0E-4
	72.000	71.969	72.031	72.000	72.000	6.0E-4
	144.000	143.969	144.031	144.000	144.000	6.0E-4
	(in)	(in)	(in)	(in)	(in)	(in)
	12.000	11.969	12.031	12.000	12.000	6.0E-4
	24.000	23.969	24.031	24.000	24.000	6.0E-4
	48.000	47.969	48.031	48.000	48.000	6.0E-4

**COMMENTS**

Example certificate, actual results and uncertainties will be reported at the time of calibration. Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.