

Fox Valley Metrology

3114 Medalist Drive

Oshkosh, WI 54902

(920) 426-5894 • Fax (920) 426-8120

<https://www.FoxValleyMetrology.com>

CERTIFICATE OF CALIBRATION



Certificate No. ACT-1272

CERTIFICATION NUMBER	CP134-00396-840	IDENTIFICATION	EL-003B								
FOR	Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902	SERIAL NUMBER	396								
TEST INSTRUMENT	Thermometer Thermocouple	PURCHASE ORDER #									
MAKE	Cole-Parmer	PROCEDURES FOLLOWED	EL-003B rev. 1								
MODEL	Digi-Sense thermometer	STANDARDS USED									
CUSTOMER LOCATION	Location1 Location2	<table><tr><td>INSTRUMENT</td><td>SERIAL NUMBER</td><td>TRACE NUMBER</td><td>NEXT CAL</td></tr><tr><td>FVC-033</td><td>5075AA1A090465</td><td>CP112-56053-337</td><td>07/31/2025</td></tr></table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVC-033	5075AA1A090465	CP112-56053-337	07/31/2025	
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL								
FVC-033	5075AA1A090465	CP112-56053-337	07/31/2025								
CONDITION RECEIVED	In Tolerance										
CONDITION RETURNED	In Tolerance										
CALIBRATED BY	Brian L Gliszinski										
REVIEWED/ISSUED	D.P. 07/29/2025										
CALIBRATION LOCATION	FVM										
ENVIRONMENT	69.0°F, 31.0%RH, 28.92inHg										
CALIBRATION DATE	05/14/2025										
RECALIBRATION DUE	05/14/2026										

CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
J-type	(°C)	(°C)	(°C)	(°C)	(°C)	(°C)
	-25.0	-26.5	-23.5	-25.0	-25.0	6.0E-2
	0.0	-1.5	1.5	0.0	0.0	6.0E-2
	100.0	98.5	101.5	100.0	100.0	6.0E-2
	250.0	248.5	251.5	250.0	250.0	6.0E-2
	500.0	498.5	501.5	500.0	500.0	6.0E-2
	750.0	748.5	751.5	750.0	750.0	6.0E-2
	1200.0	1198.5	1201.5	1200.0	1200.0	6.0E-2

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration.
Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.