

**CERTIFICATE OF
 CALIBRATION**



Certificate No. ACT-1272

CERTIFICATION NUMBER CP134-00184-840 FOR Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902 TEST INSTRUMENT Thread Micrometer Standards MAKE Mitutoyo MODEL 167-294 RANGE 1" 60° ACCURACY see cert data CUSTOMER LOCATION Location1 Location2 CONDITION RECEIVED In Tolerance CONDITION RETURNED In Tolerance CALIBRATED BY Lois Schelvan REVIEWED/ISSUED D.P. 07/29/2025 CALIBRATION LOCATION FVM ENVIRONMENT 69.0°F, 31.0%RH, 28.92inHg CALIBRATION DATE 05/14/2025 RECALIBRATION DUE 05/14/2026	IDENTIFICATION DM-018A SERIAL NUMBER 184 PURCHASE ORDER # PROCEDURES FOLLOWED DM-018A rev. 1 STANDARDS USED <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>FVM-077</td> <td>6252</td> <td>CN355-20297-616</td> <td>12/30/2025</td> </tr> <tr> <td>FVM-079B</td> <td>16783188.37</td> <td>C0141-15985-690</td> <td>05/31/2025</td> </tr> <tr> <td>FVM-094</td> <td></td> <td>C0255-17651-421</td> <td>09/30/2026</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVM-077	6252	CN355-20297-616	12/30/2025	FVM-079B	16783188.37	C0141-15985-690	05/31/2025	FVM-094		C0255-17651-421	09/30/2026
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL														
FVM-077	6252	CN355-20297-616	12/30/2025														
FVM-079B	16783188.37	C0141-15985-690	05/31/2025														
FVM-094		C0255-17651-421	09/30/2026														



CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Length	(in) 1.00000	(in) 0.99985	(in) 1.00015	(in) 0.99991	(in) 0.99991	(in) 1.2E-4
Angle	(DecDeg) 60.000	(DecDeg) 59.500	(DecDeg) 60.500	(DecDeg) 59.999	(DecDeg) 59.999	(DecDeg) 6.7E-3

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration. Nominal and limits may vary based on actual make/model.

- This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024
- Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.") Uncertainties expressed in nominal units.
- The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.