

Fox Valley Metrology

3114 Medalist Drive
 Oshkosh, WI 54902
 (920) 426-5894 • Fax (920) 426-8120
<https://www.FoxValleyMetrology.com>

CERTIFICATE OF CALIBRATION



Certificate No. ACT-1272

<p>CERTIFICATION NUMBER CP134-00036-840</p> <p>FOR Sample Manufacturing 3121 Medalist Drive Oshkosh, WI 54902</p> <p>TEST INSTRUMENT Wire Gage</p> <p>MAKE Starrett</p> <p>MODEL 283 (.007-.3125)</p> <p>CUSTOMER LOCATION Location1 Location2</p> <p>CONDITION RECEIVED In Tolerance</p> <p>CONDITION RETURNED In Tolerance</p> <p>CALIBRATED BY Mark Adamski</p> <p>REVIEWED/ISSUED D.P. 07/29/2025</p> <p>CALIBRATION LOCATION FVM</p> <p>ENVIRONMENT 69.0°F, 31.0%RH, 28.92inHg</p> <p>CALIBRATION DATE 05/14/2025</p> <p>RECALIBRATION DUE 05/14/2026</p>	<p>IDENTIFICATION DM-025A</p> <p>SERIAL NUMBER 36</p> <p>PURCHASE ORDER #</p> <p>PROCEDURES FOLLOWED DM-025A rev. 1</p> <p>STANDARDS USED</p> <table border="1"> <thead> <tr> <th>INSTRUMENT</th> <th>SERIAL NUMBER</th> <th>TRACE NUMBER</th> <th>NEXT CAL</th> </tr> </thead> <tbody> <tr> <td>FVM-077</td> <td>6252</td> <td>CN355-20297-616</td> <td>12/30/2025</td> </tr> <tr> <td>FVM-079B</td> <td>16783188.37</td> <td>C0141-15985-690</td> <td>05/31/2025</td> </tr> </tbody> </table>	INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL	FVM-077	6252	CN355-20297-616	12/30/2025	FVM-079B	16783188.37	C0141-15985-690	05/31/2025
INSTRUMENT	SERIAL NUMBER	TRACE NUMBER	NEXT CAL										
FVM-077	6252	CN355-20297-616	12/30/2025										
FVM-079B	16783188.37	C0141-15985-690	05/31/2025										



CALIBRATION RESULTS

* DENOTES "OUT OF TOLERANCE"

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
Diameters	(in)	(in)	(in)	(in)	(in)	(in)
	0.0070	0.0060	0.0080	0.0068	0.0068	1.1E-4
	0.0078	0.0068	0.0088	0.0080	0.0080	1.1E-4
	0.0085	0.0075	0.0095	0.0081	0.0081	1.1E-4
	0.0093	0.0083	0.0103	0.0095	0.0095	1.1E-4
	0.0100	0.0090	0.0110	0.0106	0.0106	1.1E-4
	0.0109	0.0099	0.0119	0.0113	0.0113	1.1E-4
	0.0125	0.0115	0.0135	0.0117	0.0117	1.1E-4
	0.0140	0.0130	0.0150	0.0134	0.0134	1.1E-4
	0.0158	0.0148	0.0168	0.0151	0.0151	1.1E-4
	0.0170	0.0160	0.0180	0.0167	0.0167	1.1E-4
	0.0187	0.0177	0.0197	0.0178	0.0178	1.1E-4
	0.0218	0.0208	0.0228	0.0209	0.0209	1.1E-4
	0.0250	0.0240	0.0260	0.0243	0.0243	1.1E-4
	0.0280	0.0270	0.0290	0.0273	0.0273	1.1E-4
	0.0312	0.0302	0.0322	0.0315	0.0315	1.1E-4
	0.0343	0.0333	0.0353	0.0344	0.0344	1.1E-4
	0.0375	0.0365	0.0385	0.0366	0.0366	1.1E-4
	0.0437	0.0427	0.0447	0.0433	0.0433	1.1E-4
	0.0500	0.0490	0.0510	0.0492	0.0492	1.1E-4
	0.0560	0.0550	0.0570	0.0557	0.0557	1.1E-4
	0.0625	0.0615	0.0635	0.0617	0.0617	1.1E-4
	0.0700	0.0690	0.0710	0.0695	0.0695	1.1E-4
	0.0780	0.0770	0.0790	0.0778	0.0778	1.1E-4
	0.0937	0.0927	0.0947	0.0932	0.0932	1.1E-4
	0.1090	0.1080	0.1100	0.1088	0.1088	1.1E-4
	0.1250	0.1240	0.1260	0.1244	0.1244	1.1E-4
	0.1400	0.1390	0.1410	0.1393	0.1393	1.1E-4

Fox Valley Metrology

3114 Medalist Drive

Oshkosh, WI 54902

(920) 426-5894 • Fax (920) 426-8120

<https://www.FoxValleyMetrology.com>

CERTIFICATE OF CALIBRATION



Certificate No. ACT-1272

FEATURE	NOMINAL	LOWER LIMIT	UPPER LIMIT	AS FOUND	AS LEFT	UNCERTAINTY
	0.1560	0.1550	0.1570	0.1555	0.1555	1.1E-4
	0.1720	0.1710	0.1730	0.1715	0.1715	1.1E-4
	0.1875	0.1865	0.1885	0.1866	0.1866	1.1E-4
	0.2030	0.2020	0.2040	0.2026	0.2026	1.1E-4
	0.2187	0.2177	0.2197	0.2177	0.2177	1.1E-4
	0.2340	0.2330	0.2350	0.2343	0.2343	1.1E-4
	0.2500	0.2490	0.2510	0.2493	0.2493	1.1E-4
	0.2650	0.2640	0.2660	0.2652	0.2652	1.1E-4
	0.2810	0.2800	0.2820	0.2814	0.2814	1.1E-4
	0.3125	0.3115	0.3135	0.3132	0.3132	1.1E-4

COMMENTS

Example certificate, actual results and uncertainties will be reported at the time of calibration.
Nominal and limits may vary based on actual make/model.

■ This certificate shall not be altered in any form or reproduced, except in full, without prior written approval from originating lab. These results relate only to the item(s) calibrated. Form Revision 10: 06/04/2024

■ Total expanded measurement uncertainties expressed are based on a confidence level of 95%; coverage factor of (k=2). The statement of compliance in this certificate was issued without taking the uncertainty of measurement into consideration. The customer shall assess the results and uncertainty when determining if the results meet their needs. (This is considered "shared responsibility.")
Uncertainties expressed in nominal units.

■ The calibrations within the certificate/report are traceable through NIST or another National Metrology Institute to the International System of Units (SI). Calibration was completed in accordance with ISO/IEC 17025:2017, ANSI/NCSL Z540-1-1994 and ANSI/NCSL Z540.3-2006. Other standards listed upon request.